



INSTRUCTION



10X20FT-BOOTH-24

STEPS

(1) Hardware




(2) Printed Graphic Fabric Banner (Optional)




STEP 01

Connect to make long poles according to labelings.



STEP 02


Connect long poles with corner poles according to labelings.



STEPS


STEP 03

Slide fabric banner on frame from top and zip up at bottom.




Same Steps for the rest back walls

Booth Set Assembly



STEP 01


Insert display stands onto feet by pressing their knobs.



STEPS


STEP 02

Interconnect display stands with C-shaped clips.



STEP 03


Screw TV mount with hex wrench.



STEPS

STEP 04

Screw light clips at top of display stands, slide lights onto them and adjust their direction.



STEPS

(1) Durable Plastic Hard Case, Aluminum Support Poles



(2) Printed Graphic Fabric Banner




STEP 01

Put hard case's top into fabric banner.



STEP 02

Insert support poles into hard case's top & bottom.



STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.

