**10X10FT-BOOTH-31**

STEPS

**(1)** Hardware

x4

(2) Printed Graphic Fabric Banner (Optional)

STEP 01 Connect to make long poles according to labelings.

x4

Press Knobs to Lock Poles with Bungees

x4

STEP 02 Connect long poles with corner poles according to labelings.

ⓐ ⓐ

ⓐ ⓐ

ⓐ Press Knobs to Lock Poles

STEP 03 Slide fabric banner on frame from top and zip up at bottom.

STEPS

STEP 04 To assemble the stand feet in position

b

**(1)** Hardware

(2) Printed Graphic Fabric Banner (Optional)

STEP 01 Connect poles according to labelings.

c **c** **c**

c Press Knobs to Lock Poles

STEP 02 Slide fabric banner on frame from left and zip up at right.

10X10FT-BOOTH-31

STEPS

(1) Hardware

x4

(2) Printed Graphic Fabric Banner (Optional)

STEP 01 Connect to make long poles according to labelings.

x4

Press Knobs to Lock Poles with Bungees

x4

STEP 02 Connect long poles with corner poles according to labelings.

Press Knobs to Lock Poles

STEPS

STEP 03
Connect support poles onto frame.

STEP 04
Slide fabric banner on frame from top and zip up at bottom, insert display stands onto feet by pressing their knobs.

Booth Set Assembly

(1) 180° C-Shaped Clip   x2

(2) Arm Clip   x2

(3) TV Mount & Screw   A

(4) LED Light & Clip   x2   x2

STEPS

STEP 01   Connect display stands with arm clips.

STEP 02   Interconnect display stands with C-shaped clips.

STEP 03   Screw TV mount with hex wrench.

TV(Excluded, Demo Only)

STEPS

STEP 04

Screw light clips at top of display stands, slide lights onto them and adjust their direction.

10X10FT-BOOTH-31

Smart Reception Counter

(1) Durable Plastic Hard Case, Aluminum Support Poles

(2) Printed Graphic Fabric Banner

STEP 01

Put hard case's top into fabric banner.

Case's Top

Fabric Banner

STEP 02

Insert support poles into hard case's top & bottom.

Case's Bottom

a

b

STEPS

STEP 04

Wrap fabric banner from bottom to top & twist it to be smooth, lay hard case's intermediate panel on podium's top.